



USO E INSTALLAZIONE SERRATURE 482 - 485 - 486

ATTENZIONE

- La serratura va montata seguendo tutte le fasi indicate nelle istruzioni seguenti di installazione
- Il montaggio non deve essere forzato
- Assicurarsi sempre del perfetto scorrimento delle eventuali aste nella porta
- Non colpire violentemente la serratura e le sue parti (non manomettere o smontare)
- Non verniciare le parti mobili
- Durante il montaggio pulire da eventuali trucioli o sporczia le sedi di alloggiamento delle serrature

MANUTENZIONE

Lubrificare le parti mobili visibili ed il cilindro con oli a base silconica (1 volta l'anno)

INSTALLAZIONE

- 1) Inserire la serratura (tenendo conto del senso di chiusura della porta) nell'apposita cava, facendo attenzione al centraggio dei ganci con i fori delle aste dei deviatori, quindi fissarla al montante con le apposite viti
- 2) Infilare il cilindro e fissarlo con la sua vite
- 3) Prima di montare i deviatori controllare se il verso di apertura dello scrocco corrisponde con quello del catenaccio della serratura. Se fosse necessario girare lo scrocco, si deve svitare completamente la vite di tenuta, estrarlo, girarlo di 180° e poi rimontarlo avvitando la vite
- 4) Infilare i deviatori nella cava inferiore e superiore, sempre assicurandosi che i ganci vadano ad inserirsi nei fori delle aste, poi serrarli con le apposite viti
- 5) Montare la maniglia e/o il maniglione antipánico seguendo le istruzioni dello stesso
- 6) Azionare, a porta aperta, le maniglie ed il cilindro per assicurarsi che tutti gli scrocchi si muovano contemporaneamente, e che il verso sia corretto
- 7) Se necessario regolare l'uscita degli scrocchi, avvitare o svitare il grano di regolazione sulla serratura (solo versione 486)

SMALTIMENTO

Non disperdere nell'ambiente il prodotto, i suoi accessori e tutti i componenti annessi. Non gettare nei normali rifiuti domestici, ma conferire ai locali sistemi pubblici di smaltimento in conformità alla normativa vigente.

- Nota informativa:**
- L'etichetta presente sulla serratura permette la rintracciabilità del prodotto.
 - La DOP è consultabile sul sito web www.mgserrature.it

OGNI MANOMISSIONE È VIETATA E COMPORTA IL DECADIMENTO DELLA MARCATURA CE



USE E INSTALLATION LOCKS 482 - 485 – 486

ATTENTION

- The lock should be installed following all the steps indicated in the following assembly instructions
- Installation should not be forced
- Always make sure the perfect sliding of any auctions in the door
- Do not violently hit the lock and its parts (not tamper with or remove)
- Do not paint the moving parts
- When installing clean from any shavings or dirt housing locks locations

MAINTENANCE

Lubricate the visible moving parts and the cylinder with silicone-based oils (1 time per year)

INSTALLATION

- 1) Insert the lock (taking into account the direction of the door closing) in the special slot, making sure to center the hooks with the holes in the auction of diverters, then secure the post with the screws
- 2) Insert the cylinder and secure it with its screw
- 3) Before mounting the switches check if the direction of the latch opening corresponds with that of the deadbolt lock. If you were to turn the latch, you must unscrew the retaining screw, pull it out, turn it 180 degrees and then reassemble it by tightening the screw
- 4) Put the switches in the inferior vena cava and superior, always making sure that the hooks go a foothold in the auction holes, then tighten them with the screws
- 5) Attach the handle and / or panic following the instructions of the same
- 6) Operating, the door is open, the handles and the cylinder to make sure that all the clips move simultaneously, and that the direction is correct
- 7) If you need to adjust the output of the latch bolts, tighten or loosen the lock on the adjustment screw (486 version only)

DISPOSAL

To disperse the product, its accessories and all related components. Do not dispose of with regular household waste, but give local public disposal systems in accordance with local regulations.

Information note:

- The label on the lock allows the traceability of the product.
- The DOP is available on the web site www.mgserrature.it

ANY TAMPERING IS PROHIBITED AND WILL VOID THE CE MARKING